

Barra	Secuencia Positiva		Secuencia Negativa		Secuencia Cero	
	Resistencia [Ω]	Reactancia [Ω]	Resistencia [Ω]	Reactancia [Ω]	Resistencia [Ω]	Reactancia [Ω]
Calabozo 230 kV	4,561	35,460	4,469	35,386	3,743	42,296
El Isiro 230 kV	6,329	55,542	5,887	55,323	1,882	34,308
La Arenosa 230 kV	0,245	4,638	0,206	4,573	0,159	1,935
La Horqueta 230 kV	0,306	5,316	0,271	5,262	0,159	2,459
Planta Centro 230 kV	0,371	7,530	0,288	7,433	0,166	4,235
El Tablazo 400 kV	2,319	24,425	2,069	23,846	1,512	16,414
La Arenosa 400 kV	0,771	13,965	0,638	13,761	1,151	9,405
La Horqueta 400 kV	0,782	15,258	0,673	15,090	0,604	8,279
Planta Centro 400 kV	0,883	15,161	0,677	14,891	0,767	9,909
Yaracuy 400 kV	1,092	15,342	0,958	15,106	0,754	8,736